



LEE ELEMENTS

Instructions

Attaching LEE Elements filters to your lens

Thread your filter clockwise onto the front of your lens until it is secure. Do not over tighten. For CPL and VND's, grip the rear fixed section of the filter whilst attaching to the lens.

LEE Elements Stoppers

Once secured to the lens, the Stopper will reduce the amount of light entering into the camera's sensor by a fixed amount. Little Stopper by 6 stops and Big Stopper by 10 stops. The actual density of your Stopper may vary by as much as 1/6 of a stop. To achieve the most accurate exposure for your individual filter, it is recommended that you make some test exposures before first use. Stoppers by design are not neutral density filters and will produce a different effect from an ND filter.

LEE Elements CPL

Once secured to the lens, rotate the front section of the filter to adjust the polarisation effect.

LEE Elements VND

Once secured in place, rotate the front section of the filter to adjust the amount of light entering the lens by the number of stops shown on the filter mount.

Hard stops at the higher and lower limit of the VND filter eliminate the risk of a full cross 'X' polarisation effect.

Some optical vignetting may be visible above 4 stops on the VND 2-5 and above 8 stops on the VND 6-9, this effect can be reduced or removed by increasing your focal length. This optical vignetting effect is the result of light travelling through both VND optics at extreme angles such as those on wide angle lenses and therefore can be best controlled via focal length adjustments.

Removing LEE Elements filters from your lens

Unthread your filter anti-clockwise until it comes away from the lens. Ensure a firm and even grip on the filter so that it does not drop off the lens when fully loosened. For CPL and VND's, grip the rear fixed section of the filter during removal.

Protective filter case

The LEE Elements protective filter case is designed with a robust latch to withstand the impact of being dropped by accident and thereby opening and releasing your filter.

To open the case, if required, you can apply a small amount of pressure using either your thumb or heel of your hand to the middle of the case over the LEE Filters logo and then use your index and middle finger to gently release the latch.



A PANAVISION COMPANY

leefilters.com